



## INSTALLATION INSTRUCTIONS

### NOVA RAIN DEFLECTOR XTREME FOR CONCURRENT SHELTER INSTALLATION

*(Right or left – read from outside facing building)*

- 1. INSTALL SHELTER:** Follow the shelter installation instructions. **Do not attach the aluminum angle to the head frame** – instead, use roofing nails through the head curtain to keep it in place. **Make sure to mount the head brackets with the shelter – the head frames will rest on top of the bracket ledge.**
- 2. ASSEMBLE RAIN PAD TO 2<sup>ND</sup> HEAD FRAME:** Remove aluminum angle from the frame. Position the pad on the frame and overlay the aluminum angle on top to align holes. Fasten angle, pad and frame together with lag screws provided (do not over tighten). Make sure to remove shipping blocks from the ends of head frame.
- 3. MOUNT HEAD FRAMES TOGETHER:** Place 2<sup>nd</sup> head frame on top of the head brackets with care taken to avoid damage to extended fiberglass section. Position frames together so that the head curtain of the shelter is in-between both frames. Drill holes through both frames and head curtain to install at least four (4) sets of thru-bolts (HH Cap Screw with 2 washers and 1 nut). Use more if necessary. **Avoid drilling through stays!**
- 4. ATTACH HEAD FRAME TO HEAD BRACKETS:** Use lag screws provided to screw on the 2<sup>nd</sup> head frame through the head brackets.
- 5. ATTACH SIDE FLAPS:** Use self-drilling screws to attach the side flaps to the head brackets. Ensure that the stay pocket is mounted to the front of the bracket.
- 6. CAULK AND FLASH BETWEEN HEAD FRAMES:** Use flashing and caulk where the head frames meet. Also caulk at the wall and under the aluminum angle. A silicone or butyl rubber caulk is recommended.

**HARDWARE PROVIDED:** 3/8"-16 x 4" Hex Head Cap Screws  
3/8" Fender Washers  
3/8"-16 Lock Nuts  
Self-Drilling Screws  
Lag Screws

## SUGGESTED MOUNTING METHODS

*(Mounting anchors not included)*

**CONCRETE BLOCK OR BRICK WALL:** Try to hit mortar joints. Use 1/2" or 3/8" x 4" expansion anchors. Use through bolt fastening (minimum 2 per frame member) if anchors will not hold – 3/8" threaded rod is recommended.

**PRECAST CONCRETE:** Same as above.

**METAL SKIN BUILDING:** Through bolt fastening as above. Use a back-up plate (steel or wood) to support bolts, or anchor through existing building girt or purlin when possible.

# RAIN DEFLECTOR TYPICAL ARRANGEMENT (WITH GS/SS/RF SERIES TRUCK SHELTER SHOWN)

